



TruTorque TTi




1

- Unlock • Déverrouiller la mollette
- Entsichern • Sbloccare • Desbloquear




2

- Adjust • Régler • Einstellen
- Regolare • Ajustar



3


- Lock • Verrouiller la molette • Sichern
- Bloccare • Bloquear



4

- Clockwise Torque Tightening
- Fonctionnement en sens horaire
- Drehrichtung im Uhrzeigersinn (Vorwärts)
- Funzionamento in Senso Orario
- Funcionamiento a derechas

- Anti-Clockwise Torque Tightening
- Fonctionnement en sens anti-horaire
- Drehrichtung im Gegenuhrzeigersinn (Rückwärts)
- Funzionamento in Senso Anti-Orario
- Funcionamiento a izquierdas



5

- Apply Torque • Appliquer le couple
- Drehmoment Anwendung • Applicare la coppia
- Aplicar el par de apriete